
MANUAL - TAG GUN MTX-05F / MTX-05R


1. Pull out the needle cover



2. Insert the fasteners with the direction of the needle



3. Push once or twice with confident move on the handle of the tag gun



4. Put the needle deep in desired spot and push on the handle of the tag gun




5. After finished work pull the little lever (1) and pull the fasteners out (2).




CHANGING THE NEEDLE IN THE TAG GUN

1. Rotate right the lock handle of the needle on the right side of the tag gun (1) and pull out



2. Put the needle (1) into the spot in the tag gun and rotate left the lock handle (2)



IMPORTANT!

- 1. After finished work, always put on the needle cover, protecting the equipment from the mechanical damage.
- 2. Use the fasteners and needles with the correct marks: for MTX-05F use fasteners "F" (F15mm,F25mm,F35mm,F40mm,F65mm) for MTX-05R use fasteners "R" (R15mm,R25mm,R35mm,R40mm,R65mm) for MTX-05F use needle "FINE" for MTX-05R use needle "REGULAR"